



Cover Size	Mounting
FM-100-L to FM 500-L	13/64" X 3/8"
FM-700-L	9/32" X 5/8"
FM-850-L	9/32" X 3/4"

See Page 37 for Lead Exits

### GENERAL DIMENSIONS

Part #	Size	A	B	C	D	E	F	G	H	J	L	Ga
FM-100-L	1	2-1/2	3-1/64	2-5/8	1-11/16	2	2-1/2	2-5/32	13/16	7/32	11/32	22
FM-200-L	1-1/8	2-13/16	3-25/64	2-15/16	1-7/8	2-1/4	2-13/16	2-15/32	1	7/32	7/16	22
FM-300-L	1-1/4	3-1/8	3-49/64	3-1/4	2	2-1/2	3-1/8	2-25/32	1-1/16	7/32	15/32	22
FM-400-L	1-3/8	3-7/16	4-9/64	3-9/16	2-1/4	2-3/4	3-7/16	3-1/16	1-3/16	7/32	21/32	22
FM-500-L	1-1/2	3-3/4	4-1/2	3-15/16	2-1/2	3	3-3/4	3-13/32	1-3/16	7/32	21/32	22
FM-700-L	1-3/4	4-3/8	5-1/4	4-7/16	3-1/8	3-1/2	4-3/8	3-7/8	1-1/2	9/32	3/4	18
FM-850-L	2-1/8	5-9/32	6-5/16	5-1/2	3-11/16	4-1/4	5-5/16	-	1-3/4	9/32	1	18

Tolerances:  
 Decimal  $\pm 0.005"$   
 Fractional  $\pm 1/64"$

Phone:(513)793-8100  
 FAX:(513)793-0624

Links E-Mail: [info@bahrsdie.com](mailto:info@bahrsdie.com)  
 Web: [www.bahrsdie.com](http://www.bahrsdie.com)



**Bahrs**  
 Die & Stamping Co., Inc.  
 4375 Rossplain Rd., Cincinnati, OH 45236